



Ceiling Mount SprinkGUARD™

Installation Instructions

Step 1

It is recommended that you consult a fire suppression installation company regarding the draining of the suppression lines before installation.

Step 2

Remove any packaging from the SprinkGUARD.

Step 3

Locate the Sprinkler head to be protected.

Step 4

Remove the ceiling tile next to the sprinkler head to be protected for access to the suppression line in order to secure the SprinkGUARD legs.

Step 5

Place the legs (2) on each side of the sprinkler line and bolt them together with the hardware provided. The legs will provide an anchor for the sprinkler cage.

Step 6

Mark the four anchor holes found in the base plate of the cage on the ceiling tile in order for drilling.

Step 7

Place the provided spacers above the ceiling tile between the legs and the ceiling tile.

Step 8

Place the SprinkGUARD cage flush on the ceiling and line it up with the pre-drilled holes.

Step 9

Slide the bolts provided through the cage baseplate, ceiling tile and spacers.

Step 10

Begin to tighten the bolt by turning in by hand.

Step 11

Tighten the bolts with a wrench or ratchet until tight.

Approved for use with the following sprinkler heads:

Reliable Model: RA1314, RA1325, RA1414, RA1425, R2921, R1712, R1722, R3612, R3622

Viking Model: VK300, VK350, VK100, VK102, VK200, VK202

Tyco Model: TY313, TY3121, TY4131, TY315, TY325, TY3211, TY3111, TY4111, TY4211

